

Zviewer For iOS 1.0 User Manual

Contents

1 Software Installation.....	3
1.1 Introduction.....	3
1.2 Environmental requirements.....	3
1.3 Installation Steps.....	3
2 Operation instruction.....	3
2.1 Opening Program.....	3
2.2 Managing Device.....	4
2.3 Playing Video.....	8
2.4 Switching Devices.....	12
2.5 Switching Channels.....	12
2.6 Switching Display Modes.....	13
2.7 PTZ Control.....	14
2.8 Image Capture.....	15

1 Software Installation

1.1 Introduction

Zviewer for iOS is the mobile app used to stream live video from your ZMODO H.264 DVR or IP Network camera, and supports a four channel simultaneous view. This guide focuses on the installation and use of the application.

1.2 Environmental requirements

Hardware: iPhone® mobile phone or iPod® touch.,
System: iOS4.3 or higher
Network: WIFI or GPRS


1.3 Installation Steps

Enter the iTunes App Store and download the Zviewer application.

2 Operation instruction

2.1 Opening Program

- 1) Locate the Zviewer application and tap to launch. Once the application loads, you will see the main interface.



Start

2.2 Managing Device

From the main interface, tap the SETTING button on the toolbar, and select Device manage (See Setting) to enter device management interface (See Devices).



- 1) **Add device.** In the device management interface (See Devices), tap ADD button on the toolbar, and enter the Add Device interface (See Add). The SAVE button will be enabled if all the required items are entered. Tap SAVE button to save and go back to the device management interface (See Devices).



Add

- 2) **Delete device.** On the device management interface (See Devices), tap EDIT button on the toolbar or swipe one row of the list (See Delete02) to delete one device.



Delete01



Delete02


- 3) **Revising device information.** From the device management interface (See Devices), tap the desired device, and make your changes (See Edit). Tap DONE button on the toolbar to save, or tap the DEVICES button to exit without saving.



Edit

2.3 Playing Video

- 1) Tap any square box; a red border will appear around the channel when chosen (See Select).



Select

- 2) Tap the PLAY button. If the channel's video player does not connect to a device, you will see a popup requesting a device selection (See Select Device). Select desired device to connect.




Select Device

- 3) From the Select Channel menu, tap the channel you would like to play (See Select Channel).



Select Channel

- 4) If the device information is correct, your video will start playing (See Play).




Play

2.4 Switching Devices

From the main interface, tap SETTINGS button on the toolbar and select the Device Connect button (or long press the square box) to enter the Select Device interface. The rest of the steps will be the same as the steps listed in Section 2.3.

2.5 Switching Channels

- 1) Tap on the CH button at the bottom of the toolbar to reveal the change channel panel (See Channel 1);
- 2) Select the desired channel you to play.
- 3) Tap the CH button again to hide the CH panel.



2.6 Switching Display Modes

- 1) Double tap the video window to switch between single channel and four channel videos;
- 2) To switch between Portrait and Landscape modes, orient your phone horizontally or vertically (See Portrait, Landscape).



Portrait



Landscape


2.7 PTZ Control

- 1) On the main interface, the bottom toolbar is above the PTZ control panel (See PTZ);
- 2) The PTZ control panel from the first row order: return to normal toolbar, tilt up, pan left, zoom in, aperture increase, focal length increase; The PTZ control panel second row order: tilt down, pan right, zoom out, aperture decrease, focal length decrease. Click the PTZ button bottom toolbar can hide the PTZ panel.

PTZ


2.8 Image

In portrait mode, SCREENSHOT button Save the file to the system.



Capture

select a video, and tap the at the bottom of the toolbar. photo directory of the



Capture